


# AIR DRIVEN BLOWER (9508)



Key	Part #	Description	Key	Part #	Description	Key	Part #	Description
	<b>9508</b>	<b>Air Driven Blower</b>	13	9800-62	Flat Washer	26	9850-09	Muffer Assembly
1	9500-80	Bolt	14	9500-79	Bolt	27	9000-16	Elbow
2	9500-72	Flat Washer	15	9500-68	Lock Nut	28	9850-95L	Lubricator
3	9500-74	Bolt	16	9534-02	Guard	29	9850-96	Gauge
4	9500-73	Lock Washer	17	9800-66	Screw	30	9895-95	Regulator
5	9500-64	Flat Washer	18	9850-61	Lubricator O-Ring	31	9850-20	Ball Valve
6	9500-03B	Gasket, Cent. Housing	19	9500-69	Acorn nut	32	9895-95F	Filter Element
7	9512-03	Chasis, Base	20	9501-03	Fan Wheel (Aluminum)	33	9850-52	Regulator Bowl
8	9504-03RM	Blower Housing (1 piece)	21	9500-91	Socket Set Screw	34	9850-63	Regulator O-Ring
9	9850-95SP	Joiner Kit	22	9505-05	Motor Bracket	35	9850-62	Lubricator Bowl
10	9504-03A	Mounting Plate	23	9505-09A	Set Key	36	9000-21	Pipe Nipple
11	9800-64	Lock Nut, Nylon	24	9850-AA	Air Motor			
12	9505-06	Rubber Feet	25	9000-01	Nipple			